


All models

Filling: only distilled water


Quantity: as required



- Check fluid level on batteries where fluid level can be seen.

If distilled water must be added, add water for overflow protection until water is no longer flowing off in overflow protection.

- On batteries where the fluid level cannot be seen, keep adding distilled water until water is no longer flowing off in overflow protection.



Note

Check fluid level more often at high outside temperatures.